

Care Instructions For Nikwax Wax Cotton Proof Waterproofing

Application (use gloves):

Protect working surface and lay fastened wet jacket on a flat clean surface.

Spray Nikwax® Colour Wax generously onto outer surface.

Spread evenly with a damp sponge or clean rag, rubbing evenly into fabric.

Check carefully to ensure no areas have been missed.

Drying: Hang up to air dry. Rub in any drips or runs. Touch up areas that may have been overlooked.

Note: Be careful and avoid spillage. Risk of staining clothes or surfaces.

Always apply this product to used waxed cotton clothing to keep items in perfect colour and water-repellent condition. Hang-up to dry and touch up any areas that have been overlooked. To maintain the performance of waterproofed gear, refer to care label and clean with Nikwax Tech Wash to remove everyday dirt and contaminants